



# 1/2" REINFORCING MULLION ASSEMBLY INSTRUCTIONS FOR WINDOWS

## YOU WILL NEED THE FOLLOWING ITEMS:

- Tape measure
- Sharp chisel
- Drill
- Hack saw
- Rubber mallet
- Sealant gun
- Geocel Pro-Flex Tri-Polymer sealant
- Mullion part A (1)
- Mullion part B (1)
- End anchor (2)
- Exterior mullion cover (1)
- Interior mullion cover (1)
- Head drip (1)
- Installation fins (4)
- 1/4" x 3" stainless steel (300 SS) flat mullion reinforcement (Not required for all applications)
- #8 x 5/8" Self drilling sheet metal screws
- #6 x 1" Flat head sheet metal screws
- #8 x 2-1/2" Flat head corrosion resistant screws

*Assembly will require two or more persons for safety reasons.*

